

WARRANTY INFORMATION (Cont.)

IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE COPE OF THIS WARRANTY.

- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.
- SOME STATES DO NOT ALLOW THE EXCLUSION NOR LIMITATION OF INCIDENTAL, CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU ALSO MAY HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

WARRANTY INFORMATION

90 DAYS LIMITED WARRANTY

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale)
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package. Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged, as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

**Southern Telecom Inc.
ATTN: Returns Department
14-C 53rd Street
Brooklyn, NY 11232**

Should you have any questions or problems concerning this product, please contact our customer service department via email at cs@southern telecom.com.

To obtain service after the warranty period, please email cs@southern telecom.com with product information, date of purchase and nature of the problem. Customer service will reply to the email with service instructions.

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification.

This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY SOUTHERN TELECOM INC.

FCC AND TELEPHONE COMPANY INFORMATION

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the Telephone company. The FCC Registration Number and Ringer Equivalence Number (REN) for this equipment. You must, upon request, provide this information to your telephone company. The REN is useful to determine the number of devices that may be connect to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connect to a line, as determined by the RENs, contact the local telephone company. [For product approved After July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label. To determine the maximum REN for your calling area.

If your telephone equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operation or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service. If you experience trouble with this telephone equipment disconnect from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company. Coection to party lines is subject to state tariffs.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequently energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment.


A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

NOTICE: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this [equipment ID] does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified Installer.

NOTICE: According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrester is recommended.

SPECIAL FEATURES



Leaving a Memo

Press and hold the PLAY/STOP button until you hear "PLEASE LEAVE YOUR MESSAGE AFTER THE BEEP". Record your message and press the  button to stop.

Screening Calls

You can screen incoming calls by listening as the caller leaves a message, if you want to talk to that caller simply pick up the phone.

Recording a Conversation

During a phone conversation, press and hold the  button until you hear a beep and the LED display shows "≡". To stop recording press the  button.

REMOTE OPERATION



You can access your answering system from any touch tone phone by entering your three digit security code. (The default security code is 000).

1. Call your telephone number.
2. After you hear the beep that follows the greeting enter your three digit security code. To bypass the greeting you can press the "*" button.
3. The answering system beeps to confirm you have accessed the remote functions, and can operate the remote functions menu.
4. Press the "*" button to listen to the remote functions menu, and select the function you want to use.

Remote Function Menu

- New messages, press 1.
- All messages, press 2.
- Erase current message, press 3.
- Erase all messages, press 3 0.
- Repeat previous message, press 4.
- Repeat the current message, press 5.
- Skip to the next message, press 6.
- Record greeting, press 7.
- Select answer on/off mode, press 9.
- To hear the remote menu, press "*" .

SETTING THE SECURITY CODE



To access this unit from an outside phone you will need to enter a 3 digit code. The default security code of this unit is **(000)**. To change the security code, press and hold down the  button at idle status. Use the ▲ or ▼ buttons to adjust, and the PLAY/STOP button to confirm. Repeat until you have set all three digits. To check your security code press and quickly release the  button.

Note: Press and quickly release the  button to hear the remote control code.


To reset the unit to the factory default settings, press and hold down the ▼ button until you hear a beep and the LED displays F.

BASIC OPERATION

Setting Answer On or Off




The answering system is on by default. Press the  button to turn the answering system off. Press the  button once again to turn the answering system back on.

Adjusting the Volume

use the electronic volume control to set the sound level. Press the  or ▼down buttons to adjust the volume to the desired level.

MESSAGE PLAYBACK

To Hear Your Messages / Memos


1. Press the PLAY/STOP button.
2. The unit will automatically playback your new messages in the order they were recieved.
3. To hear your old messages, press the PLAY/STOP button after hearing your new messages.
4. To skip to the next message press the  button.
5. To repeat the currently played message, press the  button once, to repeat the previous message, press the  button twice.
6. To pause a message press the PLAY/STOP button, you may resume the message by pressing the PLAY/STOP button once again.

RECORDING YOUR OUTGOING ANNOUNCEMENT

To record your own personalized outgoing message:

1. Press and hold down the [GREETING] button until you hear one beep tone, and the LED displays "≡"
2. Speak clearly towards the built in microphone.

While recording your greeting, you should be no more than 6 inches away from the unit, and eliminate as much background noise as possible.

3. When finished, press the  button and, your greeting plays back automatically.

NOTE: You have 60 seconds recording time for your outgoing message. If your unit beeps while you are recording, you have exceeded the time limit. Record a shorter outgoing message.

Sample Message:

"Hello, this is _____ I can't come to the phone right now, please leave your name and phone number after the beep. Thank you for calling."








Checking Your Outgoing Message

1. Press and quickly release the [GREETING] button.
2. Your outgoing announcement will be played back to you and your system will reset to answer incoming calls.

Erasing The Greeting




To erase the greeting, press the [ERASE] button while your greeting is playing.

SETTING THE TIME AND DAY

Press and hold down the  button until you hear the hour setting. Press  or  to adjust the hour and press the PLAY/STOP button to confirm. When you have completed setting the hour, the unit will enter the minute setting. Press  or  to adjust the minute and press the PLAY/STOP button to confirm. When you have completed setting the minute, the unit will enter the weekday setting. Press  or  to adjust the weekday and press the PLAY/STOP button to confirm.


Note: Press and quickly release the  button to check the time and day.

SETTING THE RINGS TO ANSWER

At idle status, press and hold down the  button to enter the ring times setting. Press  or  button to adjust and press the PLAY/STOP button to confirm.

NOTE: If you select Toll Save, when you access your messages from another phone the answering system answers after the second ring if you have new messages, and after six rings if there are no new messages.

INSTALLATION (Cont.)



2. Plug the line cord into a modular wall jack. Make sure the plug snaps firmly in place.
3. Plug the AC Adaptor into a standard 120 Volt wall outlet.

NOTE:

The jack RJ11C of the fixed line cord complies to FCC Part 68.

NOTE:

Only use the provided EM1250 AC Adaptor with your answering system.

UNDERSTANDING YOUR MESSAGE COUNTER DISPLAY

The message counter displays information about the digital answering system status.

MESSAGE COUNTER DISPLAY	REASON	ACTION
"F" flashes in the message counter display.	Memory is full.	Erase all or some messages
"0" and "A" alternately show in the message counter display.	There is no new messages, and the answering system is in the ON status.	No action required. Unit is ready to receive calls.
"0" and "—" show in the message counter display.	There is no new messages, and the answering system is in the OFF status.	Press ON to turn ON your answering system.
Numbers 1-9 and A alternately show in the display	New messages have been received.	Press PLAY to hear your messages.
"≡" shows in the message counter display.	System is in the Record status.	Unit is ready to record greeting, memo, or conversations
"E" shows in the message counter display.	System is in the ICM or remote status.	No action required. Unit is ready to receive calls.
"F" shows in the message counter display.	Unit Confirms it has been reset	System is reset to factory default settings.

IMPORTANT SAFETY INSTRUCTIONS

(Cont.)

a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

12. Do not use the telephone to report a gas leak in the vicinity of a leak.

13. Do not allow anything to rest on power cord. Do not locate this product

where the cord will be abused by persons walking on it.

14. Do not dispose of the battery(ies) in a fire. The cell may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

INSTALLATION INSTRUCTIONS

1. Never install telephone wiring during a lightning storm.

2. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

3. Never touch uninsulated telephone

wires or terminals unless the telephone line has been disconnected at the network interface.

4. Use caution when installing or modifying telephone lines.

INSTALLATION

Choose Your Location

Your unit must be placed on a hard, flat surface and connected to both the telephone wall jack and an AC power source. Allow at least one inch to the rear and four inches above the unit for ventilation.

Connect to Telephone Line

1. Plug your telephone into the modular TEL-LINE jack in the back of your unit (Fig. A).

NOTE: We do not recommend that you plug a cordless telephone into your unit. Operation of a digital answering system may cause interference on your cordless telephone.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety procedures should always be followed to reduce risk of fire, electric shock and injury to persons including the following:

1. Read and understand all instructions.

2. Follow all warnings and instructions marked on the product.

3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.

Use a damp cloth for cleaning.

4. Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

5. Do not place this product on an unstable cart, stand, or table. The product may fall causing serious damage to the product.

6. Slots and openings in the cabinet and the back or bottom are provided for ventilation, to protect from overheating. These openings must not be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation unless proper ventilation is provided.

7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.

8. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage

points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.

9. To reduce the risk of electric shock, do not disassemble this product, but take it to a qualified serviceman when some service or repair is required.

Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.

10. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

A. When the power cord or plug is damaged or frayed.

B. If liquid has been spilled into the product.

C. If the product has been exposed to rain or water.


D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions because improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.

E. If the product has been dropped or the cabinet has been damaged.

F. If the product exhibits a distinct change in performance.

11. Avoid using a telephone (other than

LOCATION OF CONTROLS



GENERAL PRODUCT CARE

To keep your answering system working and looking good follow these guidelines:

1. Avoid putting it near heating appliances and devices that generate electrical noise (for example: motors or fluorescent lamps).
2. DO NOT expose to direct sunlight or moisture.
3. Avoid dropping the answering system, and/or other rough treatment.

4. Clean with a soft cloth
5. Never use a strong cleaning agent or abrasive powder because this will damage the finish.
6. Retain the original packaging in case you need to ship it at a later date.



Digital Answering System

Model EM1250