

# Function



**BIG BUTTON PHONE WITH REMOTE  
CONTROLLER AND HELP FUNCTION  
CALLER ID AND ONE TOUCH DIALING**

**MODEL: FC-1125**

**Version No.: FC-1125 ES1**

## **USER MANUAL**

- Please follow instructions for repairing if any otherwise do not alter or repair any parts of device except specified.

### **IMPORTANT SAFETY INSTRUCTIONS**

Before using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid or Aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.
5. Do not place this product on an unstable cart, stand, or table. The product may fall causing serious damage to the product.
6. Slots and openings in the enclosure and the back and bottom are provided for ventilation, to protect it from overheating. These openings must not be blocked or covered. The opening should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation unless proper

ventilation is provided.

7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.

8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.

9. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

10. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.

11. Do not disassemble this product, but take it to a qualified service technician or service center when repair work is required. Opening or removing covers may expose you to voltage or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.

12. Unplug this product from the wall outlet and refer to qualified service personnel under the following conditions:

- A. When the power supply cord or plug is damaged or frayed.
- B. If liquid has been spilled into the product.

C. If the product has been exposed to rain or water.

D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and may require extensive work by a qualified technician to restore the product to normal operation.

E. If the product has been dropped or the enclosure has been damaged.

F. If the product exhibits a distinct change in performance.



13. Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning.

14. Do not use the telephone to report a gas leak in the vicinity of a leak.

15. Never install telephone wiring during a lightning storm.

16. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.

17. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.



1	Handset	13	Vol+
2	LCD Display	14	Redial/Pause
3	Set Key	15	Callback
4	911 Key	16	Speaker
5	Help Record Key	17	M1/M2/M3 Memory Keys
6	Cancel/ Record Key	18	In-Use Lamp
7	LOW BATT Key	19	SOS Key
8	Out key	20	Dialing Keys of 0-9, *, #
9	Delete/Flash	21	Ringer Volume Switch
10	Down	22	DC9V Jack
11	Up/Sync	23	Parallel Phone Port
12	Vol-	24	External Line

## INSTALLATION

### Coil Cord Connection

Insert coil cord into modular jack located on left hand side housing. Connect the other end into the modular jack located on handset.




### Line Cord Connection

Insert the modular plug of the straight cord into the rear side of base unit, insert the other end of RJ11 plug into the wall jack. Insert the power adaptor into the wiring board.



**Sketch Map for Replacing**

**Battery of Remote Controller**



**Loosen the screw, open  
the rear cover and  
replace it. The battery  
spec: 12V/27A**

## **Make a Call**

You can pick up the handset or push SPEAKER key then dial the number you want using the (0-9) key, or you can enter the number you want using the (0-9) keys at on-hook state, then pick up the handset or push SPEAKER key, the number will be automatically dialed out.

In another way, whether the phone is on-hook or off-hook, press one memory key of M1, M2 or M3, it will turn on the speakerphone to make a call. You can pick up the handset if you wish to talk privately.

At off-hook or handsfree speakerphone state, press [REDIAL/PAUSE] key to redial the last dialed number.

At on-hook state, when you find your desired number while checking the incoming call or outgoing call entries, press [CALLBACK] key to directly dial out it.

## **Function and Operation of Phone**

### **Setting the Function**

Set the Date

At on-hook state, press [SET] key, it will show “-12345-” on LCD display, then press number 1, the LCD will show the blinking YEAR. Then press [UP/SYNC] and [DOWN] key to adjust it. After the setting of Year is finished, press [SET] key to confirm and enter the setting of Month. The Month is set in the same way for Year, and then set Day, Hour, Minute likewise.

### Set the Flash Time

At on-hook state, press [SET] key, it will show “-12345-” on LCD display, then press number 2, the LCD will show “FLASH 1000”, it means that the flash time is 1000mS. Press [UP/SYNC] and [DOWN] key to adjust it among 100 mS, 300 mS, 600 mS and 1000 mS. After the setting is finished, press [SET] key to confirm.

### Setting the Out-of-area Code (OAC)

At on-hook state, press [SET] key, it will show “-12345-” on LCD display, then press number 3 and enter the setting

of OAC, the LCD will show “OCODE-”. Press [UP/SYNC] and [DOWN] key to set the number of OAC. After the setting is finished, press [SET] key to confirm.

#### Set the Local Area Code (LAC)

At on-hook state, press [SET] key, it will show “-12345-” on LCD display, then press number 4 and enter the setting of LAC, the LCD will show “AREA-”. Press [UP/SYNC] and [DOWN] key to set the number of LAC. After the setting is finished, press [SET] key to confirm.

#### Set the Brightness

At on-hook state, press [SET] key, it will show “-12345-” on LCD display, then press number 5 and enter the setting of brightness, the LCD will show “LCD-3”. Press [UP/SYNC] and [DOWN] key to adjust the brightness of LCD. After the setting is finished, press [SET] key to confirm.

#### [UP/SYNC] Key and [DOWN] Key

Press [UP/SYNC] and [DOWN] key to view the CID numbers in sequence. The display contents on screen include CID number, incoming call time, the serial No. of CID entry. If there is no any CID entry, LCD will show “NO CODE”.

#### [OUT] Key

Press [OUT] key at on-hook state to browse the outgoing call entries including the outgoing call number, the outgoing call time length, the serial No. of outgoing call entry.

#### [DEL/FLASH] Key

At on-hook state, when a CID call or outgoing call entry is found and needs to be deleted, press [DEL/FLASH] key once to delete it.

At off-hook state, pressing [DEL/FLASH] key is just the same to tap the hookswitch once.

## [VOL+] Key and [VOL-] Key

At the communication state, press these two keys to adjust the handset or speakerphone volume among 4 steps.

## [911] Key

Whether at on-hook state or off-hook state, the phone can enter the speakerphone state to make a call by pressing [911] key. If you want to talk privately, you can lift the handset for conversation. After the conversation is finished, the phone will automatically hang up according to the hang-up busy tone from other party.

### Changing the Number of 911:

At on-hook state, input the number from keypad + [SET] key + [911] key

## [LOW BATT PROMPT] Key

When [LOW BATT PROMPT] key lamp is lit up, it gives the prompt to replace the battery of remote controller in time.

## See the **Sketch Map for Replacing Battery of Remote**

**Controller.** After you press this key, the failure prompt is removed.

## Set M (Memory) Key

### 1) Set or Change M Key:

At on-hook state, press the private number + press # key + press the corresponding M key

### 2) Delete M Key:

At on-hook state, press # key + press the corresponding M key

### 3) Removing key top use a small flat headed screwdriver

Place it on the right side of the key and gently pull up

## Alarm Help Function

### ● **One-touch Emergency Help Function**

Whether at on-hook state or off-hook state, press the red [SOS] key, the SOS key lamp blinks and the phone generates the alarm, then automatically dials the emergency help number.

### ● **Push-down Help Function**

Lift the handset or press [SPEAKER] key for x seconds (depended on the customer's demand) without any dial operation, the SOS key lamp blinks and the phone generates the alarm, then automatically dials the emergency help number.

### ● **One-touch Help Function of Remote Controller**

Whether at on-hook state or off-hook state, press and hold the red [SOS] key on the remote controller for a second, the phone generates the alarm, then automatically dials the emergency help number.

### **Set the SOS Number**

At on-hook state, press and hold the red [SOS] key for 3 seconds, input the first SOS number from keypad. If there is already an SOS number, press [DEL/FLASH] key once to delete it, and input the new number via keypad, then press [SET] key to confirm.

At that time, input the second SOS number from keypad, then press [SET] key to confirm. If not required to set the

second SOS number, directly press [SET] key to confirm and skip over.

Notes:

1. If there is a false trigger alarm, the alarm for help can be revoked by pressing [CANCEL/RECORD] key, lifting the handset or off-hook/on-hook in the handsfree mode.
2. In the process of communication or making a call, in the event of emergency, press the red [SOS] key on phone or remote controller, the phone will cut off the call and directly dial out the SOS number.
3. After the phone has dialed out the SOS number, if the answering party hangs up his/her phone, the phone will automatically hang up according to the busy tone signal.
4. At on-hook state, press and hold [\*] key for 3 seconds to set the enable/disable function of SOS help prompt tone.
5. If the power adapter is not connected, the SOS does not alarm when it asks for help.



## **Call Answering Function via Remote Controller**

When there is an incoming call, press the red [SOS] key on remote controller, the phone will automatically off-hook in the handsfree mode and begin the handsfree conversation.

## **Alarm Records**

- Request information records and cancellation help records can be saved (up to 30 groups each) or checked, and the earliest group can be automatically cleared if more than 30 groups.
- As long as you press the remote controller or [SOS] key, the telephone will send the alarm to the platform and the alarm information will be saved to the [HELP RECORD], which can be cyclically searched through [HELP RECORD] key.
- If it is a false alarm, after the cancellation operation, the phone will record the cancellation time and save it to the [CANCEL RECORD], which can be cyclically searched through [CANCEL/RECORD] key.

## **CONSUMER INFORMATION**

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier of US:

If requested, this number must be provided to the telephone company.

The applicable jacks (i.e. RJ11C) for this equipment are provided in the packaging with each piece of approved equipment. The jacks are certified by Universal Service Order Codes (USOC).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug are provided with this product. They are designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. [For products approved

after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.]

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If you experience trouble with this equipment, disconnect it from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alter or repair any parts of device except specified.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

This equipment is hearing aid compatible.

**NOTICE:** If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**SERVICE:** According to FCC regulation. This equipment which has been certified and registered by the FCC, may only be repaired by authorized person, the FCC certification may be voided. Should you encounter any problems, please call the FUTURE CALL LLC.

Toll-free Customer Hotline for assistance:

**1-888-934-CALL, Monday - Friday between the hours of 9:00 am - 6:00 pm PST**

For general inquires, you can E-Mail to [futurecall@onvol.net](mailto:futurecall@onvol.net) or visit our website at [www.future-call.com](http://www.future-call.com)

**FOR WARRANTY AND OUT-OF WARRANTY SERVICE:**

You may call our toll-free hot line on 1-888-934-CALL (1-888-934-2255) 9AM-6PM PST or E-mail to [help@future-call.com](mailto:help@future-call.com)

**STOP...doesn't take unit back to the store.**  
**LOOK...for the toll-free "help" telephone number.**  
**LISTEN... as our experts talk you through the problem.**

For immediate answers to your questions regarding operation, missing parts or installation call:

**FUTURE CALL LLC**  
**HOTLINE & E-MAIL AT:**  
**1-888-934-CALL & [help@future-call.com](mailto:help@future-call.com)**

#### **LIMITED WARRANTY AND SERVICE**

FUTURE CALL LLC. warrants this product to be free from defective materials or factory workmanship and will replace or repair this unit or any part thereof, except batteries, if it proves to be defective in normal use or service within 90 days from

date of original purchase. Our obligation under this warranty is the repair or replacement of the defective instrument or any part thereof, except batteries. This warranty will be considered void if unit is tampered with, improperly serviced, or subjected to misuse, negligence or accidental damage.

There are no other

express warranties other than those stated herein.

This warranty gives you specific legal rights, and you may also have other rights which varies from state to state. TO

OBTAIN SERVICE PLEASE E-MAIL US ON  
[help@future-call.com](mailto:help@future-call.com) OR CALL US TOLL FREE  
1-888-934-CALL 9AM-6PM PST  
(1-888-934-2255). IF THE UNIT IS UNDER WARRANTY  
PROOF OF PURCHASE MUST BE PROVEN.